

MR SLAT® PVC Slatwall Installation Guide

Professional • Clean • Built for Long-Term Use

Before You Begin

Tools Required: Drill, level, measuring tape, screwdriver, pencil, mounting screws (#8 or #10).

Wall Types: Drywall with studs, concrete wall, plywood wall.

Step 1 – Mark the Installation Line

Use a level to mark a straight horizontal reference line on the wall. This line will guide the alignment of the first slatwall panel and ensure a clean, professional finish.

Step 2 – Install the First Panel

Align the first MR SLAT panel with the reference line. Secure the panel through the pre-formed mounting slots directly into wall studs. Recommended screw spacing is every 16–24 inches (40–60 cm).

Step 3 – Continue Panel Installation

Interlock the next panel above or below the installed one. Ensure a tight fit before fastening. Check level alignment for each panel to maintain a uniform appearance.

Step 4 – Cut Panels if Needed

Panels can be cut to fit corners, outlets, or custom wall dimensions. Trimmed edges should be placed against walls or corners for a clean look.

Step 5 – Install Accessories

Once panels are fully secured, insert MR SLAT hooks, bins, baskets, or shelves into the slots. Accessories can be repositioned at any time to meet changing storage needs.

Professional Tips

- Secure at least 80% of screws into wall studs for maximum load capacity.
- Use genuine MR SLAT accessories to ensure safety and performance.
- For large residential or commercial projects, professional installation is recommended.

© MR SLAT – Designed for Organized Canadian Spaces